

A quick guide

Wohlklang Ciccolino

You got a handmade highly customized mobile sound-system that will serve your ears everywhere you take it with you.

I do really hope that it always will give the most of it - a brilliant sound.

The case is based on birch tree that is treated several times with floor oil and finally waxed.

What's in


- 2x15 Watts Tang Band Speaker W3-993SB
- 2x15 Watts 4 Ohm Amplifier, Class D from Sure-Hifi based on the TA2024
- Bluetooth receiver from Sure-Hifi
- Powered on a Lithium Ion package, 12V 4,5 A
- A Charger

The panel on the rear

Plug additional audio source into "Line In".

Switch the main Power marked "Amp."

And last but not least:
The connector for the charger. As shown the inner pin is plus.



Into "Line Out" you can use the Bluetooth Hifi Stereo for your Hifi at home.

When using this option, turn off the Amp by flickering the switch marked "BT".

Just in case, if you lost or forgot the origin charger, follow the instructions.

Charging

The charger indicates with the red LED that it is plugged in. When it is loading the green LED is on.

The front

On top you will be engaged with the excellent frequency response of the Tang Band Speakers. Hopefully as long as possible with the joy of quality of sound.

On the bottom, two white LEDs visualize activity. One is the main power, the other Bluetooth. When one is blinking the Bluetooth is awaiting a connection. A steady glow indicates a successful connection.

Enjoy **Wohlklang**